
Test Plan Design Report

Test Project: ReHAB-T

Test Plan: Pre-flight Smoke Test (Integrated)

Printed by TestLink on 03/03/2019

2012 © TestLink Community

Table Of Contents

OBC.mega328

Startup

- rehab-t-1: Startup - Complete
- rehab-t-110: Startup - No GPS
- rehab-t-111: Startup - No SD Card
- rehab-t-2: GPS parser
- rehab-t-3: Outgoing Telemetry
- rehab-t-4: Outgoing COM-housekeeping request
- rehab-t-5: Incoming COM-housekeeping
- rehab-t-22: Internal Temperature
- rehab-t-24: External Temperature
- rehab-t-6: Timing
- rehab-t-7: SD-card
- rehab-t-8: Timeouts

COM.RFxxx

- rehab-t-9: Startup
- rehab-t-10: Incoming Telemetry message
- rehab-t-11: Incoming Housekeeping request
- rehab-t-13: Incoming Radio Message
- rehab-t-23: Internal Temperature

Integrated Flight System

Flight Operations

- rehab-t-34: Radio Downlink
- rehab-t-35: Radio Uplink
- rehab-t-30: Telemetry - Valid GPS
- rehab-t-31: Telemetry - Invalid GPS
- rehab-t-82: Telemetry - No GPS Connection
- rehab-t-32: House keeping
- rehab-t-33: Environmental Data
- rehab-t-93: BEACON mode

Preconditions

- rehab-t-85: Integrated Tests

EPS proto

- rehab-t-99: Power Output
- rehab-t-100: Low voltage operation
- rehab-t-101: Start Pin

Test Project: ReHAB-T

Test Project for ReHAB Technological missions

Test Suite : OBC.mega328

Test Suite : Startup

Test Case rehab-t-1: Startup - Complete

Summary:

Check if module starts up properly after Vcc-ON

- GPS Initialization
- Buzzer test
- SD-card init
- LOG created
- Default values before GPS fix

Preconditions:

1. Connect OBC to Bus Analyzer if not integrated.
2. Connect GPS module or GPS simulator
3. Insert SD Card

<u>#:</u>	<u>Step actions:</u>	<u>Expected Results:</u>
1	Turn on power	System starts. Startup message transmitted on debug port
2	GPS Initialization	GPS configured properly
3	SD-Card init	SD Card Initialized
4	Buzzer Test	Buzzer beeps five times (Everything Initialized)
5	Telemetry Message	Contains default GPS values
6	Check SD-Card	LOG files created
<u>Execution type:</u>	Manual	
<u>Estimated exec. duration (min):</u>		
<u>Priority:</u>	Medium	

Test Case rehab-t-110: Startup - No GPS

Summary:

Check if module starts up properly after Vcc-ON

- GPS Initialization
- Buzzer test
- SD-card init
- LOG created
- Default values before GPS fix

Preconditions:

1. Connect OBC to Bus Analyzer if not integrated.
2. Do not connect GPS module or GPS simulator
3. Insert SD Card

<u>#:</u>	<u>Step actions:</u>	<u>Expected Results:</u>
1	Turn on power	System started Startup Message sent on debug line
2	GPS init	GPS init failed with "Airborne Mode Error"
3	Buzzer	Buzzer beeps three times
<u>Execution type:</u>	Manual	
<u>Estimated exec. duration (min):</u>		
<u>Priority:</u>	Medium	

Test Case rehab-t-111: Startup - No SD Card

Summary:

Check if module starts up properly after Vcc-ON

- GPS Initialization
- Buzzer test
- SD-card init
- LOG created
- Default values before GPS fix

Preconditions:

1. Connect OBC to Bus Analyzer if not integrated.
2. Connect GPS module or GPS simulator
3. Do not insert SD Card

<u>#:</u>	<u>Step actions:</u>	<u>Expected Results:</u>
1	Turn on power	System started Startup Message sent on debug line
2	SD Card init	SD Card init fails with "No SD Card" message
3	Buzzer	One long beep
<u>Execution type:</u>	Manual	
<u>Estimated exec. duration (min):</u>		
<u>Priority:</u>	Medium	

Test Case rehab-t-2: GPS parser

Summary:

Check GPS parser operation

- GPGLA
- Time
- Latitude, Longitude
- Altitude
- GPS Fix

<u>#:</u>	<u>Step actions:</u>	<u>Expected Results:</u>
1	First GPS Fix	As the first fix established buzzer beeps two times
2	GPS latitude on Northern hemisphere	latitude format: +DDmm.mmm
3	GPS latitude on Southern hemisphere	latitude format: -DDmm.mmm
4	GPS longitude on Eastern hemisphere	longitude format: +DDDmm.mmm
5	GPS longitude on Western hemisphere	longitude format: -DDmm.mmm
6	GPS altitude under 32 767 m	
7	GPS altitude over 32 767 m	
<u>Execution type:</u>	Manual	
<u>Estimated exec. duration (min):</u>		
<u>Priority:</u>	Medium	

Test Case rehab-t-3: Outgoing Telemetry

Summary:

Check TMLTM packet format on UPRA-BUS SICL line

```
$TMLTM, hhmmss, plllll. lll, pyyyyy. yyy, aaaaa, eeee, oooo*cc
```

hhmmss	GPS Time : hh-hours, mm-minutes, ss-seconds
pllll. lll	GPS Latitude : p : + N, - S, llll. lll-latitude NMEA format
pyyyyy. yyy	GPS Longitude : p : + E, - W, yyyyy. yyy-longitude NMEA format
aaaaa	GPS Altitude in Meters
eeee	External Temperature : eeee/10 °C
oooo	OBC Temperature : oooo/10 °C
*cc	Checksum

sample:

```
$TMLTM, 123541, +4807.038, +01131.000, 00545, 0123, 0123*47
```

GPS Time: 12:35:41 (UTC)

Coordinates: N 48.1173, E 11.51677 (decimal)

Altitude: 545m

External Temperature: 12.3°C

OBC Module Temperature: 12.3°C

<u>Execution type:</u>	Manual
<u>Estimated exec. duration (min):</u>	
<u>Priority:</u>	Medium

Test Case rehab-t-4: Outgoing COM-housekeeping request

Summary:

Check TMHKR housekeeping data request on UPRA-BUS SICL

\$TMHKR,m,,*cc

m	Module ID
*cc	Checksum

Module ID

- C - COM
- D - DAU
- E - EPS
- S - Complete System (GND only)
- P1 - Payload1
- P2 - Payload2
- P3 - Payload3

Execution type:	Manual	
Estimated exec. duration (min):		
Priority:	Medium	
Relations	blocks - rehab-t-5:Incoming COM-housekeeping	

Test Case rehab-t-5: Incoming COM-housekeeping

Summary:

TCHKD Message processing, incoming on UPRA-BUS SICL

\$TCHKD, t, v, m*cc

t	Module temperature in centigrade: (t/10)°C
v	Module BusVoltage (m/100)V
m	Number of sent telemetry packets
*cc	Checksum

sample:

\$TCHKD, 0123, 336, 198*47

temperature: 12.3°C

busvoltage: 3.36 V

sent messages: 198

#:	Step actions:	Expected Results:	
1	OBC Send TMHKR on SICL	COM respond to message with TCHKD	
2	Check TCHKD format on SICL	Format matches	
3	Check message ID ('m')	Message ID matches	
4	Check temperature data in Telemetry Log on SD Card	Temperature data stored correctly	
5	Test for connection timeout: 1. Disconnect COM from BUS 2. OBC Send TMHKR on SICL	<ul style="list-style-type: none">No response on BUSOBC returns with timeout	
<u>Execution type:</u>	Manual		
<u>Estimated exec. duration (min):</u>			
<u>Priority:</u>	Medium		
<u>Relations</u>	depends on - rehab-t-4:Outgoing COM-housekeeping request		

Test Case rehab-t-22: Internal Temperature

Summary:

Check internal module temperature value:

- in TMLTM message
- in Telemetry Log on SD Card

Preconditions:

Use an external thermometer as control

Module should run for at least 5 mins before measurement

<u>#:</u>	<u>Step actions:</u>	<u>Expected Results:</u>
1	Check temperature in TMLTM message	Temperature value is valid (only minimal difference to the control thermometer)
2	Check temperature in Telemetry Log on SD Card	Temperature value is valid (only minimal difference to the control thermometer) Tmeperature matches TMLTM temp data
<u>Execution type:</u>	Manual	
<u>Estimated exec. duration (min):</u>		
<u>Priority:</u>	Medium	

Test Case rehab-t-24: External Temperature

Summary:

Check external temperature from MCP9700:

- in TMLTM message
- in Telemetry Log on SD Card

Preconditions:

Use an external thermometer as control

Module should run for at least 5 mins before measurement

<u>#:</u>	<u>Step actions:</u>	<u>Expected Results:</u>
1	Check temperature in TMLTM message	Temperature value is valid (only minimal difference to the control thermometer)
2	Check temperature in Telemetry Log on SD Card	Temperature value is valid (only minimal difference to the control thermometer) Tmeperature matches TMLTM temp data
<u>Execution type:</u>	Manual	
<u>Estimated exec. duration (min):</u>		
<u>Priority:</u>	Medium	

Test Case rehab-t-6: Timing

<u>Summary:</u>	
Check if timing for automated functions is properly set	
<u>Execution type:</u>	Manual
<u>Estimated exec. duration (min):</u>	
<u>Priority:</u>	Medium

Test Case rehab-t-7: SD-card

Summary:

Check SD card related functions

- Log created
- Log in correct format
- Missing SD Card

#:	Step actions:	Expected Results:						
1	Check SD Card for log	Telemetry Log created: data.csv						
2	Check Telemetry Log format	time	latitude	longitude	altitude	ext_temp	OBC_temp	COM_temp
		hhmmss	(+/-)ddmm.mmmmm	(+/-)dddmm.mmmmm	a	ddd [0.1°C]	ddd [0.1°C]	ddd [°C]
		Sample: time,latitude,longitude,altitude,ext_temp,OBC_temp,COM_temp<CR><LF> 336677,+9500.000,+18888.000,0,217,227,022<CR><LF> 336677,+9500.000,+18888.000,0,420,153,022<CR><LF> 093735,+4728.40460,+01903.65498,105,194,263,022<CR><LF>						
3	Remove SD Card while OBC still operates	OBC returns "file error" error						
4	Insert SD Card with no restart after Step #3	Successful logging						
5	Restart OBC without SD Card	OBC returns "No SD CARD" error						
6	Insert SD Card with no restart after Step #5	OBC returns "No SD CARD" error						
Execution type:	Manual							
Estimated exec. duration (min):								
Priority:	Medium							

Test Case rehab-t-8: Timeouts

Summary:

Check if no deadlocks stop the operation

- GPS timeout
- Message timeouts

<u>#:</u>	<u>Step actions:</u>	<u>Expected Results:</u>	
1	Disconnect GPS Module	GPS timeout occurs	
2	Reconnect GPS module	Nominal operation	
3	Disconnect a subsystem	SICL timeout occurs	
4	Reconnect subsystem	Nominal operation	
<u>Execution type:</u>	Manual		
<u>Estimated exec. duration (min):</u>			
<u>Priority:</u>	Medium		

Test Suite : COM.RFxxx

Test Case rehab-t-9: Startup

Summary:

COM module start up

Start up Message format:

\$TCSTR,u,a*cc

u	UHF transceiver startup (0-inactive, 1-active)
a	APRS transmitter startup (0-inactive, 1-active)
*cc	Checksum

sample:

\$TCSTR,1,0*cc

UHF is present, APRS is not present

Preconditions:

Connect BUS-TESTER to COM module to monitor SICL operations

#:	Step actions:	Expected Results:	
1	Turn power on	COM module starts up Startup message sent on SICL Startup message in correct format	
Execution type:	Manual		
Estimated exec. duration (min):			
Priority:	Medium		

Test Case rehab-t-10: Incoming Telemetry message

Summary:

Incoming Telemetry message:

- TMLTM processed
- Telemetry radio packet created in proper format
- Radio packet sent via RF transceiver

UHF Telemetry packet format:

\$\$CCCCC,iii,hhmmss,(+/-)xxxx.xxx,(+/-)xxxxx.xxx,aaaaa,eeee,ooo,rrr,

\$\$	START bytes
CCCCC	callsign
iii	Message ID*
hhmmss	GPS time (UTC) (hh-hours, mm-minutes, ss-seconds)
(+/-)xxxx.xxx	latitude (NMEA format)
(+/-)xxxxx.xxx	longitude (NMEA format)
aaaaa	altitude (m)
eeee	external temperature (*10 °C -> eee.e°C)
ooo	OBC module temperature (*10 °C -> ooo°C)
rrr	COM module temperature (*10 °C -> rrr°C)

* Message ID shows the last three digits of the sent message and increments with every new message. After COM restart the Message ID set back to 0.

<u>Execution type:</u>	Manual
<u>Estimated exec. duration (min):</u>	
<u>Priority:</u>	Medium

Test Case rehab-t-11: Incoming Housekeeping request

Summary:

Incoming Housekeeping request message:

- TMHKR processed
- Housekeeping data read properly
- TCHKD messages sent in proper format

<u>Execution type:</u>	Manual
<u>Estimated exec. duration (min):</u>	
<u>Priority:</u>	Medium

Test Case rehab-t-13: Incoming Radio Message

Summary:

Incoming radio message processing

- Handshake sent automatically

Execution type: Manual

Estimated exec.
duration (min):

Priority: Medium

Test Case rehab-t-23: Internal Temperature

Summary:

Check internal module temperature value:

- in TCHKD message

Preconditions:

Use an external thermometer as control

Module should run for at least 5 mins before measurement

<u>#:</u>	<u>Step actions:</u>	<u>Expected Results:</u>
1	Check temperature in TCHKD message	Temperature value is valid (only minimal difference to the control thermometer)

Execution type: Manual

Estimated exec.
duration (min):

Priority: Medium

Test Suite : Integrated Flight System

Test Suite : Flight Operations

Test Case rehab-t-34: Radio Downlink

Summary:

Check radio downlink, message format, message data

- OBC+COM+EPS+GPS
- Battery Powered
- GPS bypass, PC simulator, valid GPS data, short, controlled datastream
- Radio link to GND

Output

- GND Logs
- DIAG Logs

<u>Execution type:</u>	Manual
------------------------	--------

<u>Estimated exec. duration (min):</u>	
--	--

<u>Priority:</u>	Medium
------------------	--------

Test Case rehab-t-35: Radio Uplink

Summary:

Check processing of incoming radio packets

- OBC+COM+EPS+GPS
- Battery Powered
- GPS bypass, PC simulator, valid GPS data, short, controlled datastream
- Radio link to GND

Output

- GND Logs
- DIAG Logs

<u>Execution type:</u>	Manual
------------------------	--------

<u>Estimated exec. duration (min):</u>	
--	--

<u>Priority:</u>	Medium
------------------	--------

Test Case rehab-t-30: Telemetry - Valid GPS

Summary:

Check telemetry processing with PC-GPS Simulator providing valid GPS messages.

- OBC+COM+EPS+GPS
- Battery Powered
- GPS bypass, PC simulator, valid GPS data, short, controlled datastream
- Radio link to GND

Output

- SD Log
- GND Logs
- DIAG Logs

<u>Execution type:</u>	Manual
<u>Estimated exec. duration (min):</u>	
<u>Priority:</u>	Medium

Test Case rehab-t-31: Telemetry - Invalid GPS

Summary:

Check telemetry processing with PC-GPS Simulator providing invalid GPS messages with no fix

- OBC+COM+EPS+GPS
- Battery Powered
- GPS bypass, PC simulator, invalid GPS data, short, controlled datastream
- Radio link to GND

Output

- SD Log
- GND Logs
- DIAG Logs

<u>Execution type:</u>	Manual
<u>Estimated exec. duration (min):</u>	
<u>Priority:</u>	Medium

Test Case rehab-t-82: Telemetry - No GPS Connection

Summary:

Check telemetry processing with PC-GPS Simulator providing invalid GPS messages with no fix

- OBC+COM+EPS+GPS
- Battery Powered
- GPS bypass, PC simulator, no GPS data (signal off), short, controlled datastream
- Radio link to GND

Output

- SD Log
- GND Logs
- DIAG Logs

<u>Execution type:</u>	Manual
------------------------	--------

<u>Estimated exec. duration (min):</u>	
--	--

<u>Priority:</u>	Medium
------------------	--------

Test Case rehab-t-32: House keeping

Summary:

Check collected house keeping data: COM module temperature, OBC module temperature

- OBC+COM+EPS+GPS
- Battery Powered
- GPS bypass, PC simulator, valid GPS data, short, controlled datastream
- Radio link to GND

Output

- SD Log
- GND Logs
- DIAG Logs

<u>Execution type:</u>	Manual
------------------------	--------

<u>Estimated exec. duration (min):</u>	
--	--

<u>Priority:</u>	Medium
------------------	--------

Test Case rehab-t-33: Environmental Data

Summary:

Check collected environmental data: External Temperature

- OBC+COM+EPS+GPS
- Battery Powered
- GPS bypass, PC simulator, valid GPS data, short, controlled datastream
- Radio link to GND

Output

- SD Log
- GND Logs
- DIAG Logs

<u>Execution type:</u>	Manual
<u>Estimated exec. duration (min):</u>	
<u>Priority:</u>	Medium

Test Case rehab-t-93: BEACON mode

Summary:

Test BEACON mode activation:

In NORMAL mode:

- Increase altitude over 1000m
- Decrease altituder under 300m

In BEACON mode:

- Increase altitude over 500m
- Decrease altitude under 300m

<u>#:</u>	<u>Step actions:</u>	<u>Expected Results:</u>
1	Increase altitude over 1000m	Stays in NORMAL mode
2	Decrease altitude under 300m	BEACON mode activates under 500m
3	Increase altitude in BEACON mode over 500m	Automatic switch to NORMAL mode over 500m
4	Decrease altitude under 300m	BEACON modes activates under 500m
<u>Execution type:</u>	Manual	
<u>Estimated exec. duration (min):</u>		
<u>Priority:</u>	Medium	

Test Suite : Preconditions

Test Case rehab-t-85: Inegrated Tests	
<u>Summary:</u> <ol style="list-style-type: none">1. Place and connect the prepared modules on the testboard2. Place and connect diagnostic cards on the testboard3. Connect additional wiring4. Properly fix the modules and cables <div>ALWAYS USE DUMMY LOAD OR ANTENNA ON RF COMPONENTS!</div>	
<u>Execution type:</u>	Manual
<u>Estimated exec. duration (min):</u>	
<u>Priority:</u>	Medium

Test Suite : EPS proto

Test Case rehab-t-99: Power Output		
<u>Summary:</u>		
Test 3v3 and 5v0 voltage output		
<u>#:</u>	<u>Step actions:</u>	<u>Expected Results:</u>
1	Connect bench PSU to Battery IN	
2	Check 3V3 output	3V0 - 3V6 output
3	Check 5V0 output	5V5 stable output
4	Check GPS voltage	GPS gets the UNREG voltage and starts up
<u>Execution type:</u>	Manual	
<u>Estimated exec. duration (min):</u>		
<u>Priority:</u>	Medium	

Test Case rehab-t-100: Low voltage operation		
<u>Summary:</u>		
Check outputs by lowering the input voltage		
<u>#:</u>	<u>Step actions:</u>	<u>Expected Results:</u>
1	Set input voltage from 6V to 4V by steps	
2	Check 3V3 output	3V0 - 3V3
3	Check 5V0 output	5V0 - 4V0
4	Check GPS voltage	GPS operates through voltage drop
<u>Execution type:</u>	Manual	
<u>Estimated exec. duration (min):</u>		
<u>Priority:</u>	Medium	

Test Case rehab-t-101: Start Pin

Summary:

Check Start Pin operation

<u>#:</u>	<u>Step actions:</u>	<u>Expected Results:</u>
1	Remove Start Pin	<ul style="list-style-type: none">• 0V at 3V3 DC-DC converter Input• 0V at 5V0 DC-DC converter Input• 0V at outputs
2	Connect Start Pin	<ul style="list-style-type: none">• Proper voltage at Outputs• UNREG voltage at DC-DC inputs
<u>Execution type:</u>	Manual	
<u>Estimated exec. duration (min):</u>		
<u>Priority:</u>	Medium	